

## ***Storm Smart Dooya Motor (Std. 4W, Remote RF or Remote w/Ov Setting Rotation & Cloning Remotes***

1. Facing Screen Determine if Motor Is on Right or Left
2. Connect Power To Motor
3. If Motor on "Right" Facing Screen
  - a. Depress "Program" Button on Rear of Rem
    1. Press "Down" Button to Set Down
4. If Motor on "Left" Facing Screen
  - b. Depress "Program" Button on Rear of Rem
    1. Press "Up" Button to Set Down Ro
5. Cloning Remotes
  - a. Press "Program" on Working Remote 2 Tim
  - b. Press "Program" on Remote to Clone Remc
6. Limits Set Manually

***eride)***

t

**ote 2 Times  
Rotation**

**ote 2 Times  
otation**

**ies  
ote 1 Time**